



# X1-Hybrid User Manual

3.0kW - 7.5kW



EN



**SolaX Power Network Technology(Zhe jiang) Co., Ltd.**

ADD:No.288 Shizhu Road, Tonglu Economic Development Zone,  
Tonglu City, Zhejiang Province, China.

Tel:+0571-5626 0011

E-mail: [info@solaxpower.com](mailto:info@solaxpower.com)

614.00495.00

## Copyright Declaration

The copyright of this manual belongs to SolaX Power Network Technology(Zhe jiang) Co.,Ltd. Any corporation or individual should not plagiarize, partially or fully copy (including software,etc.), and no reproduction or distribution of it in any form or by any means. All rights reserved. SolaX Power Network Technology (Zhe jiang) Co.,Ltd. reserves the right of final interpretation. The contents are subject to change without prior notice.

[www.solaxpower.com](http://www.solaxpower.com)

## Contents

<b>1 Note on this Manual .....</b>	<b>03</b>
1.1 Scope of Validity .....	03
1.2 Target Group .....	03
1.3 Symbols Used .....	03
1.3.1 Important Safety Instructions .....	04
1.3.2 Explanation of Symbols .....	09
1.3.3 CE Directives .....	10
<b>2 Introduction .....</b>	<b>11</b>
2.1 Basic Feature .....	11
2.2 System Diagram .....	11
2.3 Work Modes .....	14
2.4 Dimension .....	16
2.5 Terminals of Inverter .....	16
<b>3 Technical Data .....</b>	<b>18</b>
3.1 DC Input .....	18
3.2 AC Output/Input .....	18
3.3 Battery .....	19
3.4 Efficiency ,Safety and Protection .....	19
3.5 Off-grid Output .....	20
3.6 General Data .....	20
<b>4 Installation .....</b>	<b>21</b>
4.1 Check for Transport Damage .....	21
4.2 Packing List .....	21
4.3 Installation Precautions .....	23
4.4 Tool Preparation .....	24
4.5 Installation Site Conditions .....	26
4.5.1 Installation Carrier Requirements .....	26
4.5.2 Installation Requirements .....	26
4.5.3 Installation Space Requirements .....	27
4.6 Mounting .....	28

<b>5 Electrical Connections</b>	<b>31</b>
5.1 PV Connection	31
5.2 Grid Port and Off-grid Output Connection	35
5.3 Off-grid Block Diagram	36
5.4 Battery Connection	44
5.5 Communication Connection	48
5.5.1 Introduction to DRM Communication	48
5.5.2 Introduction to Meter/CT Communication	49
5.5.3 COM Communication	53
5.5.4 Communication Connection Steps	54
5.6 Grounding (mandatory)	59
5.7 Monitoring Connection	61
5.8 Check All Below Steps Before Starting Inverter	63
5.9 Inverter Operation	64
<b>6 Firmware upgrading</b>	<b>65</b>
<b>7 Setting</b>	<b>69</b>
7.1 Control Panel	69
7.2 Menu Structure	70
7.3 LCD Operation	71
<b>8 Troubleshooting</b>	<b>95</b>
8.1 Trouble Shooting	95
8.2 Routine Maintenance	101
<b>9 Decommissioning</b>	<b>102</b>
9.1 Disassemble the Inverter	102
9.2 Packaging	102
9.3 Storage and Transportation	102
9.4 Waste Disposal	102
<b>10 Disclaimer</b>	<b>103</b>

## 1 Notes on this Manual

### 1.1 Scope of Validity

This manual is an integral part of X1-Hybrid G4. It describes the assembly, installation, commissioning, maintenance and failure of the product. Please read it carefully before operating.

X1 -Hybrid-3.0-D	X1 -Hybrid-3.7-D	X1 -Hybrid-5.0-D	X1 -Hybrid-6.0-D	X1 -Hybrid-7.5-D
X1 -Hybrid-3.0-M	X1 -Hybrid-3.7-M	X1 -Hybrid-5.0-M	X1 -Hybrid-6.0-M	X1 -Hybrid-7.5-M

Note: "X1-Hybrid G4" Series refers to the energy storage inverter that supports photovoltaic grid-connected.

"5.0" means 5.0kW.

"D" means with "DC Switch", "M" means externally attached

X1-Matebox for full load off-grid operation.





Keep this manual available at any time.

### 1.2 Target Group

This manual is for qualified electricians. The tasks described in this manual only can be performed by qualified electricians.

### 1.3 Symbols Used

The following types of safety instructions and general information appear in this document as described below:



### 1.3.1 Important Safety Instructions

#### Danger!



Danger to life due to high voltages in the inverter! The personnel responsible for the installation, electrical connection, debugging, maintenance and fault handling operation of this product need to be trained, master the correct operation method, have the corresponding electrician qualification and safety operation knowledge.

#### Caution!



When the inverter is working, it is strictly forbidden to touch the shell. The temperature of the shell can be high and there is a risk of scalding.

#### Caution!



Radiation may be harmful to health! Do not stay for a long time and keep at least 20 cm away from the inverter.

#### Attention!



Ground PV system. Finish PV modules and photovoltaic system grounding in accordance with local requirements to achieve optimal protection of systems and personnel.

#### Warning!



Ensure that the input DC voltage is below the inverter limit. Excessive DC voltage and current may cause permanent damage or other losses to the inverter, which is not covered by the warranty.

#### Warning!



Authorized service personnel must disconnect the AC and DC power supply of the inverter before performing any maintenance, cleaning or operation of any circuit connected to the inverter.



#### Warning!

The inverter can not be operated when it is running.



#### Warning!

Risk of electric shock!

Strictly follow relevant safety specifications for product installation and testing. During installation, operation or maintenance, please read carefully and follow the instructions and precautions on the inverter or user manual. If the operation is incorrect, it may cause personal and property losses. Please keep the user manual properly after use.

This inverter can only use the accessories sold and recommended by SolaX, otherwise it may cause fire, electric shock or casualties.

Without the authorization of our company, you may not open the inverter cover or replace the inverter parts, otherwise the warranty promise of the inverter will be invalid.

The use and operation of the inverter must be carried out in accordance with the instructions in this manual, otherwise this protection will fail and the warranty of the inverter will also fail.

During working, the inverter surface temperature may exceed 60°C, please make sure the inverter cools down before touching, and make sure children can not touch.

When exposed to sunlight, photovoltaic arrays generate dangerous high DC voltages. Please follow our instructions, otherwise it will be life-threatening.

All DC and AC power sources must be disconnected from the inverter for at least 5 minutes before any wiring or electrical operation is performed on the inverter to ensure complete isolation of the inverter and avoid electric shock.

A photovoltaic module used on the inverter must have a IEC61730A rating, and the total open circuit voltage of the photovoltaic string / array is lower than the maximum rated DC input voltage of the inverter. Any damage caused by photovoltaic over voltage is not covered by warranty.

Installation position should be away from wet environment and corrosive substances.

After the inverter and power grid cut off the PV power supply, there will be a certain amount of residual current in a short time, be cautious or it may lead to serious personal injury and even high risk of death. Use a multimeter (impedance at least 1 Mohm) to measure the voltage between the UDC and the UDC- to ensure that the inverter port is discharged below the safe voltage before starting operation (35VDC).

#### ➤ Surge protection devices (SPDs) for PV installation

##### Warning!



Over-voltage protection with surge arresters should be provided when the PV power system is installed. The grid connected inverter is fitted with SPDs in both PV input side and MAINS side.

Direct or indirect lightning strikes can cause failures. Surge is the main cause of lightning damage to most devices. Surge voltage may occur at photovoltaic input or AC output, especially in remote mountain areas where long distance cable is supplied.

Please consult professionals before installing SPDs.

The external lightning protection device can reduce the influence of direct lightning strike, and the lightning protection device can release surge current to the earth.

If the building installed with external light protection device is far away from the inverter location, in order to protect the inverter from electrical and mechanical damage, the inverter should also install an external lightning protection equipment.

In order to protect DC system, two-stage surge protection equipment is needed between DC cable of inverter and photovoltaic equipment module.

In order to protect the AC system, the level 2 surge protection equipment should be installed at the AC output, located between the inverter and the grid. Installation requirements must comply with IEC61643-21 standard.

All DC cables shall be installed in a distance as short as possible, and the positive and negative cables of the same input need to be bundled together to avoid causing loops in the system. Minimum distance installation and binding requirements also apply to auxiliary grounding and shielding grounding conductors.

#### ➤ Anti-Islanding Effect


The islanding effect means that when the power grid is cut off, the grid-connected power generation system fails to detect the power outage and still supplies power to the power grid. This is very dangerous for the maintenance personnel and the power grid on the transmission line.

X1-Hybrid G4 series inverters use active frequency offset method to prevent islanding effect.

#### ➤ PE Connection and Leakage Current

- All inverter incorporate a certified internal Residual Current Device (RCD) in order to protect against possible electrocution and fire hazard in case of a malfunction in the PV array, cables or inverter. There are 2 trip thresholds for the RCD as required for certification (IEC 62109-2:2011). The default value for electrocution protection is 30mA, and for slow rising current is 300mA.

- If an external RCD is required by local regulations, check which type of RCD is required for relevant electric code. It recommends using a type-A RCD. The recommended RCD values is 100mA or 300mA unless a lower value is required by the specific local electric codes.



- A faulty ground connection can result in equipment failure, personal and death injuries, and electromagnetic interference.
- Ensure correct according to grounding to IEC62109 and conductor diameter according to STANDARD specification.
- Do not connect the grounding end of the equipment in series to prevent multi-point grounding.
- Electrical appliances must be installed in accordance with the wiring rules of each country.

#### For United Kingdom

- The installation that connects the equipment to the supply terminals shall comply with the requirements of BS 7671.
- Electrical installation of PV system shall comply with requirements of BS 7671 and IEC 60364-7-712.
- All protective devices cannot be changed.
- User shall ensure that equipment is so installed, designed and operated to maintain at all times compliance with the requirements of ESQCR22(1)(a).

#### ➤ Battery Safety Instructions

SolaX X1-Hybrid G4 Series inverter should pair with high voltage battery, for the specific parameters such as battery type, nominal voltage and nominal capacity etc., please refer to section 3.3.

Please refer to the matching battery specification for details.

#### 1.3.2 Explanation of Symbols

This section gives an explanation of all the symbols shown on the inverter and on the type label

##### • Symbols on the Inverter

Symbol Explanation	Explanation
	Operating Display
	Battery status
	An error has occurred, please inform your installer immediately

##### • Symbols on the Type Label

Symbol	Explanation
	CE mark. The inverter complies with the requirements of the applicable CE guidelines.
	TUV certified.
	RCM remark.
	SAA certification.
	Beware of hot surface. The inverter can become hot during operation. Avoid contact during operation.
	Danger of high voltages. Danger to life due to high voltages in the inverter!
	Danger. Risk of electric shock!
	Observe enclosed documentation.
	The inverter can not be disposed together with the household waste. Disposal information can be found in the enclosed documentation.

	<p>Do not operate this Inverter until it is isolated from battery, mains and on-site PV generation suppliers.</p>
	<p><b>Danger to life due to high voltage.</b> There is residual voltage existing in the inverter after powering off, which needs 5 min to discharge. • Wait 5 min before you open the upper lid or the DC lid.</p>

### 1.3.3 CE Directives

This chapter describes the requirements of the European low voltage regulations, including safety instructions and system licensing conditions, the user must comply with these regulations when installing, operating, and maintaining the inverter, otherwise it will cause personal injury or death, and the inverter will cause damage.

Please read the manual carefully when operating the inverter. If you do not understand "danger", "warning", "caution" and the description in the manual, please contact the manufacturer or service agent before installing and operating the inverter.

Grid-connected inverter comply with low voltage directive (LVD) 2014/35/EU and Electromagnetic compatibility directive (EMC) 2014/30/EU. Detection of components is based on:

EN 62109-1:2010 ;  
EN 62109-2:2011 ;  
IEC 62109-1(ed.1) ;  
IEC62109-2(ed.1)  
EN 61000-6-3:2007+A:2011 ;  
EN 61000-6-1:2007 ;  
EN 61000-6-2:2005;

For installation in photovoltaic module system, it is necessary to make sure that the whole system complies with the requirements of EC(2014/35/EU,2014/30/EU, etc.) before starting the module (i.e. to start the operation). The assembly shall be installed in accordance with the statutory wiring rules. Install and configure the system in accordance with safety rules, including the use of specified wiring methods. The installation of the system can only be done by professional assemblers who are familiar with safety requirements and EMC. The assembler shall ensure that the system complies with the relevant national laws.

The individual subassembly of the system shall be interconnected by means of the wiring methods outlined in national/international such as the national electric code (NFPA) No.70 or VDE regulation 0107.

## 2 Introduction

### 2.1 Basic Features

X1-Hybrid G4 series is a high-quality inverter that can convert solar energy into alternating current and store energy into batteries. The inverter can be used to optimize self-consumption, stored in batteries for future use or fed into the public grid. The way it works depends on user preferences. It can provide emergency power during power outages.

### 2.2 System Diagram

X1-Hybrid G4 series are designed to have four Off-grid wiring schemes, customers can choose Off-grid compatible parts Load and Off-grid compatible with all load use.

There are different ways of wiring in different countries, one is to connect N line with PE line, the other is to separate the line from the PE line wiring, see below;

**Diagram A: Neutral line and PE line are separated from each other, and the common load is connected to the off-grid port; (For most countries)**




Diagram B: Neutral line and PE line are separated from each other, all loads connect to the Off-grid port;(For most countries)




Diagram C: Neutral line and PE line are combined together, and the common load is connected to the off-grid port;(Apply to Australia)





Diagram D: Neutral line and PE line are combined together, all loads connect to the Off-grid port;(Apply to Australia)



#### Note!

- When power cuts suddenly, the inverter connects the N line of off-grid load with the ground through relay, providing a fixed zero potential for off-grid load and ensuring the safety of electricity use by users.
- Please control the inverter load and make sure it is "output value" in "within" Off-grid mode, otherwise the inverter will stop and alarm overload fault".
- Please confirm with the grid operator whether there are special regulations for grid connection.

## 2.3 Work Modes

X1-Hybrid G4 series, can be based on different needs, there are a variety of models.

### Self Use

The self-use mode is suitable for areas with low feed-in subsidies and high electricity prices.

① When the power of PV is sufficient

Active Charging or Discharge time period: PV will power the loads firstly, and surplus power will charge to the battery. If the battery is fully charged, then sell the surplus power to the grid; (The inverter will limit the output if Feed-in limit or zero feed-in is needed )

(PV > Load, PV → Load → Battery → Grid)

② When the power of PV is insufficient

Active Charging time period: PV will power the loads firstly, the remaining power will be taken from the grid, the battery will not discharge at this time.

(PV < Load, PV + Grid → Load)

Active Discharge time period: PV+BAT will power the loads together. If the power is still not enough, the remaining power will be taken from the grid.

(PV < Load, PV + Battery + Grid → Load)

③ Without PV power


Active Charging time period: The grid supplies the loads and also can charge the battery;

(PV=0, Grid → Load + Battery)

Active Discharge time period: The battery will power the home loads firstly. If the battery power is not enough, the remaining power will be taken from the grid. The inverter will enter into the standby state.

(PV=0, Battery + Grid → Load)

Battery min SOC can be set: 10%~100%



### Feed-in priority

The Feed-in priority mode is suitable for areas with high feed-in subsidies, but has feed-in power limitation.

① When the power of PV is sufficient

Active Charging time period: PV will power the loads firstly, and surplus power will feed-in to the grid. If the feed-in power has been limited, the surplus power can charge the battery.

(PV > Load, PV → Load → Grid → Battery)

Active Discharge time period: PV will power the loads firstly, and surplus power will feed-in to the grid.

(PV > Load, PV → Load → Grid)


② When the power of PV is insufficient

Active Charging time period: PV will power the loads firstly, the remaining power will be taken from the grid. The battery will not discharge.

(PV < Load, PV + Grid → Load)

Discharge time period: PV+BAT will power the loads together. If the power is still not enough, the remaining power will be taken from the grid.

(PV < Load, PV + Battery + Grid → Load)



③ Without PV power


Active Charging time period: The grid will power the home loads and also charge the battery;

(PV=0, Grid → Load + Battery)

Active Discharge time period: The battery will power the home loads firstly. If the battery power is not enough, the remaining power will be taken from the grid. The inverter will enter into the standby state.

(PV=0, Battery + Grid → Load)

Battery min SOC can be set: 10%~100%




### Backup mode

The back-up mode is suitable for areas with frequent power outages.

Same working logic with "Self-use" mode. This mode will maintain the battery capacity at a relatively high level. (Users' setting) to ensure that the emergency loads can be used when the grid is off. Customers no need to worry about the battery capacity.

Battery min SOC can be set: 30%~100%

Backup mode SOC adjustment range: 30%~100%; In Backup mode, SOC-min under off-grid condition is 10%, which cannot be modified;



### Off-grid

The off-grid is used when the power grid is off. System will provide emergency power through PV and batteries to supply power to the household loads.

(Battery must be installed for this mode)

① When the power of PV is sufficient

PV will power the loads firstly, and surplus power will charge to the battery.

(PV > Load, PV → Load → Battery)

② When the power of PV is insufficient

The remaining power will be taken from the battery.

(PV < Load, PV → Load)


③ Without PV power

The battery will power the emergency loads until the battery reached the min SOC, then the inverter will enter into the idle mode.



(PV=0, Battery → Load)

Note: in the case of grid connection, all working modes work normally when the battery SOC > 5%. When the battery charge rate is below 5%, the PV or Grid will first charge the battery SOC 11%, and then return to the working mode selected by the user.

## 2.4 Dimension



## 2.5 Terminals of Inverter



Object	Description
A	DC switch
B	PV connection port
C	Battery connection port
D	USB port for upgrading
E	Battery communication
F	Meter/CT Port
G	CAN is a reserved port
H	Load/Off-grid Output
I	Ground connection port
J	External monitoring connection port
K	DRM Port(only for Australia)
L	Communications/ LCD is a reserved port
M	Waterproof valve
N	Fans(only for X1-Hybrid-7.5-D and X1-Hybrid-7.5-M )



Warning!

Qualified electrician required for the installation.

### 3 Technical Data

#### 3.1 DC Input

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
	X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M
Max. recommended PV power [W]	4500	5500	7500	9000	10000
Max. DC voltage [V]	600	600	600	600	600
Nominal DC operating voltage [V]	360	360	360	360	360
MPPT voltage range [V]		70-550			
MPPT Full Power voltage range [V]	115-480	135-480	190-480	225-480	280-480
Max. input current [A]	14/14	14/14	14/14	14/14	14/14
Max. short circuit current [A]	16/16	16/16	16/16	16/16	16/16
Start output voltage [V]	90	90	90	90	90
No. of MPP trackers	2	2	2	2	2
Strings per MPP tracker	1	1	1	1	1

#### 3.2 AC Output/Input

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
	X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M
<b>AC Output</b>					
Nominal AC power [VA]					
3000					
3680					
5000(Germany 4600, AU4999)					
6000					
7500					
Max. apparent AC power [VA]					
3300					
3680					
5500(Germany 4600, AU4999)					
6600					
7500					
Rated AC voltage [V]					
220/230/240 (180 to 270)					
Rated grid frequency [Hz]					
50/60					
MaxAC current [A]					
144					
16					
23.9(Germany 20, AU21.7)					
28.6					
32.6					
Displacement power factor					
0.8 leading...0.8 lagging					
Total harmonic distortion (THD)					
< 2%					
<b>AC Input</b>					
Max. apparent power [VA]					
6300					
7360					
9200					
9200					
9200					
Rated AC power [W]					
3000					
3680					
5000					
6000					
7500					
Rated grid voltage (range) [V]					
220/230/240 (180 to 270)					
Rated grid frequency [Hz]					
50/60					
MaxAC current [A]					
27.4					
32					
40					
40					
Displacement power factor					
0.8 leading...0.8 lagging					

#### 3.3 Battery

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
	X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M
Battery type	Lithium batteries				
Battery Full Voltage [V]	80-480				
Maximum charge/discharge flow [A]	30A				
Communication interface	CAN/RS485				
Reverse connection protection	Yes				

#### 3.4 Efficiency, Safety and Protection

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
	X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M
MPPT efficiency					
99.9%					
European efficiency					
97.0%					
Maximum efficiency					
97.6%					
Max. battery charge efficiency (PV to BAT) (@ full load)					
97.0%					
Max. battery discharge efficiency (BAT to AC) (@ full load)					
97.0%					
<b>Security &amp; Protection</b>					
DC SPD Protection					
Integrated (Type II)					
AC SPD Protection					
Integrated (Type II)					
Over/under voltage protection					
YES					
Grid protection					
YES					
DC injection monitoring					
YES					
Back feed current monitoring					
YES					
Residual current detection					
YES					
Anti-islanding protection					
YES					
Over load protection					
YES					
Over heat protection					
YES					
Array insulation resistance detection					
YES					

### 3.5 Off-grid Output

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M	
Off-grid rated [VA] power	3000	3680	5000	6000	7500
Off-grid rated voltage [V]		230VAC			
Frequency [Hz]		50/60			
Off-grid rated current [A]	13	16	21.7	26.1	32.6
Off-grid Peak Power [VA]	120%rated,1h	120%rated,1h	120%rated,1h	120%rated,10min	100%rated
Switching time( typical value) [ms]	internal switch<10,external switch<100				
Total harmonic distortion (THDv)	<2%				

### 3.6 Generic Data

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D		
X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M			
Dimensions (W/H/D)[mm]	482*417*181						
Dimensions of Packing (W/H/D)[mm]	590*530*315						
Net weight [kg]	22	22	22	22	23		
Gross weight [kg]	27	27	27	27	28		
Heat dissipation treatment	Natural Cooling			Forced airflow			
Noise emission(typical)[dB]	<30			<45			
Storage temperature range [°C]	-40~+70						
Operating temperature range [°C]	-35~+60 (derating at 45)						
Humidity [%]	0%~100%						
Altitude [m]	<3000						
Protection level	IP65						
Security level	I						
Cold standby consumption	<2W						
Over voltage category	III(MAINS),II(PV, Battery)						
Pollution Degree	III						
Installation mode	Wall mounted						
Inverter Topology	non-isolated						
Communication interface	Meter/ CT, external control RS485, Pocket series (optional), DRM/USB						
Standard warranty	Standard 10 years						


## 4 Installation

### 4.1 Check for Transport Damage

Ensure that the inverter is in good condition via transportation. If there is any visible damage such as cracks, please contact the dealer immediately.

### 4.2 Packing List

Open the package and check the materials and accessories according to the following list.



Number	Quantity	Description
A	1	X1-Hybrid G4 series inverter.
B	1	Bracket
C*	1	Waterproof connector with RJ45
D*	4	PV terminal (positive*2, negative*2)
E*	4	PV pin angle(positive*2, negative*2)
F*	3	8AWG European terminals
G*	1	OT terminal(inverter grounding)
H	3	(Expansion bolt, Gasket, Self-tapping bolt)*3
I*	2	10AWG European terminals
J	1	M5 inner hexagon bolt
K*	4/3	Waterproof connector with RJ45 (COM/CAN/DRM/CT)
L	2	Battery connection terminals(positive*1, negative*1)
M	1	RJ45 terminals
N	1	Manual
O	1	Quick Installation Guide
P	1	Warranty Card
Q▲	1	Pocket WiFi
R	1	Meter( optional )
S*	1	CT

Note: \*C\* \ \*D\* \ \*E\* \ \*F\* \ \*G\* \ \*I\* and \*S\* accessories are not included in the accessory package of M series inverter, but included in X1-Matebox.

\*Q\* is the standard part of M-series inverter and the optional part of D-series inverter.

\*K\* The inverter in Australia needs to be connected to DRM, which is 1 more communication line adapter than that in other countries, while the other countries only need 2 communication line adapters.

### 4.3 Installation Precautions

The protection level of X1-Hybrid G4 series inverters is IP 65, so that the inverter can be installed outdoors.

Check the installation environment and pay attention to the following conditions when installing:


- Do not expose to strong light.
- Do not touch flammable building materials.
- Do not approach flammable and explosive gases or liquids (e.g. where chemicals are stored).
- Do not touch cold air directly.
- Do not approach TV antenna or cable.
- Do not place in areas above 3000 meters above sea level.
- Do not install in precipitation or high humidity, which may cause corrosion or damage Internal devices.
- Keep the system out of reach of children.

If the inverter is installed in a narrow area, be sure to reserve appropriate space for heat dissipation.

The ambient temperature of the installation site is -35°C~60°C.


The maximum angle range of wall tilt  $\pm 5^\circ$ .

Avoid direct sunlight, rain and snow weather.



#### 4.4 Tool preparation

Tool equipment				
Type	Name	Image	Name	Image
Machine Installation Tools	Hammer drill		Multimeter	
	Torque screwdriver		Socket wrench set (Hexagon)	
	OT terminals press clamp		Diagonal pliers	
	Utility knife		Multifunction terminal crimping tool (RJ45)	
	Diagonal pliers		Marker	
	Rubber hammer		Tape ruler	
	Crimping Tool		Hexagon keys	
	Euro terminal crimping tool		Spirit level	
	Individual Protection Tools		Protective glasses	

Tool equipment				
Type	Name	Image	Name	Image
Individual Protection Tool	Safety gloves		Safety shoes	
Requirement				
Equipment Preparation	Breaker		Grid port and Off-grid port wiring section (4.5.2)	
Cable Preparation	PV end wire		Dedicated PV wire, line number #12 AWG withstand voltage 1000V, temperature resistance 105°C fire resistance grade VW-1	
	Off-grid end wire		Double Core Cables	
	Grid end wire		Triple Core Cables	
	Communication lines		Twisted pair with shield	
	Battery Cable		Conventional wire	
	PE Cable		Conventional wire	

## 4.5 Installation Site Conditions

### 4.5.1 Installation Carrier Requirements


Do not install the inverter near flammable materials.

Please install the inverter on a solid object that can withstand the weight requirements of the inverter and energy storage system.

Please be careful not to install the inverter in the plasterboard wall or similar to the residential places with poor sound insulation, so as not to work with noise and interfere with the residents' life in the morning.


### 4.5.2 Installation Requirements

Install the inverter at a maximum back tilt of 5 degrees, the inverter can not be tilted forward, inverted, excessive back tilted or side tilted.



### 4.5.3 Installation Space Requirements


Reserve enough space when installing inverter (at least 300mm) for heat dissipation.



Reserved space dimensions of installation

Position	Min Distance
Left	300mm
Right	300mm
Up	300mm
Down	300mm
Forward	300mm

The distance of installation space for multiple inverters is as follows:



## 4.6 Mounting

### ➤ Preparation

Please prepare the following tools before installation.





Installation tools: screwdriver, wrench,  $\Phi 10$  drill, hammer, socket wrench set and Hexagon keys.

### ➤ Step 1: Fix the wall bracket to the wall.

First find the expansion screw and the wall bracket in the accessory bag, as shown below:





a) Use a marker to mark drilling holes of the bracket on the wall .Drill holes at marked spots with depth of 80mm.



### ➤ Step 2: hang the inverter on the bracket.

c) Insert expansion bolt into the hole, use rubber hammer to knock the expansion screw bolt into the wall;


d) The bracket is aligned with the screw uses the inner hexagonal wrench to screw the tapping screw until the expansion bolt "bang" is heard.




➤ Step 3: Tighten the inverter and bracket.

e) Hang the buckle on the inverter to the corresponding position of the backplane;

f) Use the inner hexagonal wrench to tighten the inner hexagonal screw on the right side of the inverter.



e)



f)

Inner hexagonal wrench  
(Torque:  $1.2\pm0.1$  N·m)

## 5 Electrical Connections

### 5.1 PV Connection

X1-Hybrid G4 series inverters have two PV inputs. Please select photovoltaic modules with good performance and quality assurance. The open circuit voltage of the module array should be less than the maximum PV input voltage specified by the inverter, and the working voltage should be within the MPPT voltage range.

The PV port wiring harness for M-series inverters has been completed, and the PV port wiring harness for D-series inverters is required

Table 1: Maximum input voltage limit

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
Max. DC input voltage	X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M

600V



**Warning!**

The voltage of photovoltaic modules is very high, and is dangerous voltage. When wiring, please follow the safe electricity regulations.



**Note!**

Do not ground the positive or negative pole of the photovoltaic module!



**Note!**


The following PV module requirements need to be applied to each input range:

1. Same model
2. Same quantity
3. The same queue
4. The same angle




**Note!**

X1-Hybrid G4 series inverters do not support the following PV module connection modes.




X1-Hybrid G4 series inverters support the following PV module connection modes.




➤ Connection step

The PV port wiring of X1-Hybrid G4 M series inverter has been completed. On X1-Matebox, the D series needs to be wired according to the following steps.


Step 1. Turn off the DC switch, connect the PV module, prepare a 12AWG PV cable, and find the PV (+) terminal and PV (-) terminal in the package.




Step 2. Use a wire stripper to strip the 7mm insulation layer of the wire end.




Step 3. Tighten the cable with the insulation layer stripped and insert it into the metal terminal (see Figure 1), make sure all wires are inserted into the metal terminal (see Figure 2).




Step 4. Tighten the PV pin needle and the wiring harness to make the connection tight without looseness




Step 5. The PV joint is divided into 2 parts - the plug and the fastening head. Insert the cable through the fastening head and the opposite plug. Note that the red and black lines correspond to different of plugs. Finally, force the cable pair into the plug, will a "click" sound which indicates that the connection is complete.




Step 6. Tighten the fastening head and into insert the corresponding positive and negative (PV-/PV+) ports of the inverter.



The following is the location of the inverter's positive and negative (PV-/PV+) ports.



Schematic diagram of the inverter PV connected.



## 5.2 Grid Port and Off-grid Output Connection

X1-Hybrid G4 series inverter are single-phase inverter inverter. Suitable for rated voltage 220/230/240V, frequency 50/60Hz. For more technical requirements ,please consult the requirements of the local public grid.

### ➤ Grid port connection

#### Grid Cable and Micro-breaker recommended

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
Cable (copper)	4-6mm <sup>2</sup>	6-8mm <sup>2</sup>	8-10mm <sup>2</sup>	8-10mm <sup>2</sup>	8-10mm <sup>2</sup>
Micro-Breaker	32A	40A	50A	50A	50A

Model	X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M
Cable (copper)	3-4mm <sup>2</sup>	3-4mm <sup>2</sup>	4-6mm <sup>2</sup>	4-6mm <sup>2</sup>	6-8mm <sup>2</sup>
Micro-Breaker	25A	25A	32A	32A	40A

#### Off-grid Cable and Micro-breaker recommended

Model	X1-Hybrid-3.0-D	X1-Hybrid-3.7-D	X1-Hybrid-5.0-D	X1-Hybrid-6.0-D	X1-Hybrid-7.5-D
X1-Hybrid-3.0-M	X1-Hybrid-3.7-M	X1-Hybrid-5.0-M	X1-Hybrid-6.0-M	X1-Hybrid-7.5-M	
Cable (copper)	3-4mm <sup>2</sup>	3-4mm <sup>2</sup>	4-6mm <sup>2</sup>	4-6mm <sup>2</sup>	6-8mm <sup>2</sup>
Micro-Breaker	25A	25A	32A	32A	40A

The circuit breaker should be installed between the inverter and the mains, and the load should not be directly connected to the inverter.




Figure: Wrong connection of load and inverter


### 5.3 Off-grid Block Diagram

X1-Hybrid G4 series inverter has an off-grid function. When the grid is connected, the inverter outputs go through the Grid port, and when the grid is disconnected, the inverter outputs go through the Off-grid port. The Off-grid function can be connected to part of the load, and it can also be used to connect to all loads. Please refer to the following diagram for the wiring. To be compatible with all loads, you will need an addition a accessory. If you need a solution, please contact our sales.


#### ➤ Off-grid wiring diagram

For to different local wiring rules, please refer to the diagram below. Please select the appropriate wiring method according to local wiring rules.

**Diagram A: Neutral line and PE line are separated from each other, and the common load is connected to the off-grid port;(For most countries)**



**Diagram B: Neutral line and PE line are separated from each other, all loads connect to the Off-grid port;(For most countries)**



**Diagram C: Neutral line and PE line are combined together, and the common load is connected to the off-grid port;(Apply to Australia)**





Diagram D: Neutral line and PE line are combined together, all loads connect to the Off-grid port;(Apply to Australia)



X1-Matebox is a convenient wiring accessory. Please refer to X1-Matebox for details. If you need to purchase X1-Matebox,



In full load scheme **Diagram B** and **Diagram D**, set "X1-Matebox" to "Enable" under Settings;  
The Australian customer must shorten the N lines of the Grid and the off-Grid in the X1-Matebox.  
If your local wiring method does not follow the above operation guide, especially the neutral wire, ground wire, RCD wire, please contact our company before operation.

#### ➤ Off-grid load requirements

##### Warning!

Ensure that the Off-grid load rated power is within the Off-grid rated output power range, otherwise, the inverter will report an "overload" warning.



When "overload" occurs, adjust the load power to make sure it is within the Off-grid rated output power range, and the inverter will automatically return to normal.

For non-linear loads, ensure that the inrush current power is within the Off-grid rated output power range.

When the configuration current is less than the maximum DC input current, the capacity and voltage of lithium battery and lead acid battery will decrease linearly.

The following table shows some common loads for your reference.

Note: Please check with the manufacturer for high-power inductive loads.

Content	Power		Common equipment	Instance		
	Start	Rated		Equipment	Start	Rated
Resistive load	X 1	X 1	Incandescent lamp	100W Incandescent lamp	100VA (W)	100VA (W)
Inductive load	X 3~5	X 2	Fan Fridge	150W Fridge	450 - 750VA (W)	300VA (W)

➤ Grid and Off-grid connection steps


● Connection requirements

Note: Check the grid voltage and compare the voltage range (see technical data).


Disconnect the circuit board from all power sources to prevent electric shock.

**The Grid and Off-grid ports of X1-Hybrid G4 M series inverter have been connected, and the D series needs to be wired according to the following steps.**


Step 1. Prepare a Grid cable (three-core wire) and an Off-grid cable (two-core wire), and then find the European terminal and waterproof cover in the accessory bag.




Step 2: The Grid and Off-grid cables go through the corresponding Grid and Off-grid ports of the waterproof cover.




Step 3. Remove the 12mm insulation layer at the end of the wire. Insert the European-style terminals respectively, and make sure that the stripped ends are inserted into the European-style terminal, and finally use crimping pliers to press tightly.




Step 4. Find the location of the AC interface on the inverter, insert the crimped terminals into the UW10 terminals L, N, and P according to the wire sequence, and use a flat-blade screwdriver to tighten the screws.  
(Torque:  $0.2\pm0.1\text{N}\cdot\text{m}$ )



Step 5. Install the AC waterproof cover, and tighten the screws on the four sides of the waterproof cover with an Allen wrench.



Step 6. Tighten the waterproof fastening head.



## 5.4 Battery Connection

### ➤ Connection requirements

X1-Hybrid G4 series inverter charge and discharge system can be equipped with high voltage lithium battery and lead acid battery. Please note that the maximum voltage of the battery should not exceed 480 V, the rated voltage of the battery should not exceed 360 V, battery communication should be compatible with the X1-Hybrid G4 inverter.


### ➤ Battery Breaker

Before connecting the battery, a non-polar DC MCB must be installed to ensure safety.

Before maintenance, the inverter need to be safely disconnected.

Model	X1-Hybrid-3.0-D X1-Hybrid-3.0-M	X1-Hybrid-3.7-D X1-Hybrid-3.7-M	X1-Hybrid-5.0-D X1-Hybrid-5.0-M	X1-Hybrid-6.0-D X1-Hybrid-6.0-M	X1-Hybrid-7.5-D X1-Hybrid-7.5-M
Voltage	Nominal voltage of DC breaker should be larger than maximum voltage of battery.				
Current[A]	32A				

### ➤ Battery connection diagram




Note:

When using SolaX batteries, the recommended number of battery modules (HV10045/HV10063/HV10058) is 1-3 units, and battery controller MC0500 unit.


### ➤ Battery connection steps:

Battery port connection line of the X1-Hybrid G4 M series inverter is on the X1-Matebox, just connect it. It is necessary to wire the D series according to the following steps.


Step 1. Prepare 8 AWG battery power line, find the DC plug (+), DC plug (-) in the accessory bag.




Step 2. Strip the insulation layer (length:15mm) at one end of the power line.




Step 3. Insert the stripped cables into the DC plug (-) and DC Plug (+) respectively.



Step 3. Press down on the spring by hand, you can hear a click sound, then push the ends together, and tighten the screw joints.




Step 4. Insert the battery power lines into the corresponding BAT port (+), (-) of the inverter.



### ➤ Communication connection

#### BMS port definition

The communication interface between the inverter and the battery uses the waterproof connector with RJ45.



- 1) White with orange stripes
- 2) Orange
- 3) White with green stripes
- 4) Blue
- 5) White with blue stripes
- 6) Green
- 7) White with brown stripes
- 8) Brown

PIN	1	2	3	4	5	6	7	8
Definition	BAT_TEMP	GND	GND	BMS_CANH	BMS_CANL	X	BMS_485A	BMS_485B



#### Note!


After the BMS communication between the battery and the inverter is finished, the battery will work normally.

## 5.5 Communication Connection

### 5.5.1 Introduction to DRM communication (AS4777 regulatory requirements)

DRM requirements:

Mode	Requirement
DRM0	Operation disconnect device
DRM1	Do not consume power
DRM2	Do not consume more than 50% of rated power
DRM3	Do not consume more than 75% of rated power AND Source reactive power if capable
DRM4	Increase power consumption (subject to constraints from other active DRMs)
DRM5	Do not generate power
DRM6	Do not generate more than 50% of rated power
DRM7	Do not generate more than 75% of rated power AND Sink reactive power if capable
DRM8	Increase power generation (subject to constraints from other active DRMs)



Remarks:

Currently only PIN6 (DRM0) and PIN1 (DRM1/5) are functional, other PIN functions are under development.

### 5.5.2 Introduction to meter/CT Communication

X1-Hybrid G4 inverter should work with an electric meter or current sensor (CT for short) to monitor household electricity usage. The electricity meter or CT can transmit the relevant electricity data to the inverter or platform, which is convenient for users to read at anytime.

Users can choose to use electric meters or CTs according to demand.


Please note that the meter/CT brand required by SolaX must be used.

#### Note!

The meter or CT must be connected to the inverter, otherwise the inverter will shut down and alarm SolaX "meter failure" alarm. Smart meters must be authorized by SolaX, third party or other companies. Unauthorized meter may be incompatible with the inverter.

SolaX will not be responsible for the impact caused by the use of other appliances.


#### ► Electric meter connection diagram



### ➤ CT Connection


The current sensor measures the current on the live wire between the inverter and the public grid.

#### • CT connection diagram



#### • LCD settings


To select CT, you need to enter Use setting, then enter CT/Meter Setting.



#### • Note for CT connection:

##### Note!

- Do not place the CT on the N wire or ground wire.
- Do not put CT on the N line and L line at the same time.
- Do not place the CT on the side where the arrow points to the inverter.
- Do not place the CT on non-insulated wires.
- The cable length between CT and inverter should not exceed 25 meters.
- After CT is connected, prevent the CT clip from falling off. It is recommended to wrap the CT clip around in circles with insulating tape.




##### Note!

Only one of the Meter and CT connections can be selected. Meter cable goes to pin terminal 4 and 5; CT cable goes to pin terminal 1 and 8; reserved CT cable goes to pin terminal 3 and 6.

➤ BMS communication cable.

The BMS pin is defined as follows:




**Note!**

The communication port on the lithium battery must be consistent with the definition of pins 4, 5, 7, and 8 above;

➤ DRM communication cable

The DRM pin is defined as follows:



**Note!**


At present, there are only PIN6 (DRM0) and PIN1 (DRM1 / 5), and other PIN functions are under development.

### 5.5.3 COM Communication

COM communication interface is mainly provided to the customer to do the second step of development use.

➤ Application occasion

COM is a standard communication interface, through which the monitoring data of the inverter can be directly obtained. Also, external communication devices can be connected to carry out the secondary development of the inverter. For specific technical docking, please contact SolaX.



➤ COM PIN Definition

1	2	3	4	5	6	7	8
X	X	X	485A	485B	X	X	X

**Note!**


The communication port on the COM must be consistent with the definition of pins 4, 5 above;

#### 5.5.4 Communication Connection Steps

Step 1. Prepare a communication cable, and then find the communication adapter in the accessory bag.



Communication cable




Waterproof connector with RJ45




RJ45 terminal


Step 2 Insert the communication cable through the communication adapter, and peel off the outer insulation layer of 15mm.




Diagonal pliers



Step 3. Insert the prepared communication cables into the RJ45 terminals in sequence , and then use network cable crimping pliers to press them tightly.




- 1) White with orange stripes
- 2) Orange
- 3) White with green stripes
- 4) Blue
- 5) White with blue stripes
- 6) Green
- 7) White with brown stripes
- 8) Brown



## ➤ METER/CT communication cable


METER/CT pin is defined as follow:

**Note!**


Only one of the Meter and CT connections can be selected..  
Meter cable goes to pin terminal 4 and 5;CT cable goes to pin terminal 1 and 8; CT2 cable goed to pin terminal 3 and 6.

1) Users can customize the length of the CT communication cable. The accessory package provides 1\*RJ45 and 1\*waterproof connector with RJ45 terminals.

When the CT cable is completed, connect the A terminal to the "CT/METER" port of the inverter and tighten the waterproof screw , and connect the B terminal to the RJ45 coupler




2) One side of the finished cable,Waterproof connector with RJ45 is inserted into the inverter, and one side of the RJ45 terminal is inserted into the CT connection.


**Note!**

When installing, pay attention to water resistance. All the connected parts of CT must be put into the distribution cabinet.

Step 4. Tighten the completed Meter/CT/BMS communication line and tighten the waterproof plug



Step 5: Finally, find the corresponding COM, METER, CT, DRM ports on the inverter and insert the communication cable into the corresponding ports.



## 5.6 Grounding Connection (mandatory)

The user must make two ground connections: one shell grounding, and one equipotential grounding. This prevents electric shock.

Note: If the PV end of the inverter is not connected with earth, the inverter will turn on a red light. Inspect and report ISO Fault. This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring.


The ground wire port of X1-Hybrid G4 M series inverter has been connected, and the D series needs to be wired according to the following steps.

### ➤ Ground connection steps:


Step 1. Prepare a one-core cable (12AWG), and then find the ground terminal in the accessories.




Step 2. Strip the grounding cable insulation (length "L2"), insert the stripped cable into the ring terminal, and then clamp it.



Step 3. Insert the stripped cable into OT terminal and tighten the terminal with a terminal crimping tool.




Step 4. Find the ground connection port on the inverter, and screw the ground wire on the inverter with an M5 Allen key.



## 5.7 Monitoring Connection (Accessories)


The inverter provides a DONGLE port, which can transmit data of the inverter to the monitoring website via Pocket WiFi Plus, Pocket 4G, Pocket GPRS, and Pocket LAN. (If necessary, purchase products from SolaX)

### ➤ WiFi connection diagram




### ➤ Wireless monitoring accessories connection steps:

Step 1. Of the DONGLE port of the inverter needs to unscrew the screw and take off the cover.



Step 2. Plug the Pocket WiFi Plus into the DONGLE port, use the screws in step 1 to tighten it.




## 5.8 Check All Below Steps Before Starting Inverter

➤ After the inverter is checked, the conduct the following steps:

- ① Make sure that the inverter is fixed on the wall.
- ② Ensure that all ground wires are grounded.
- ③ Confirm that all DC lines and AC lines are connected.
- ④ Make sure the CT is connected.
- ⑤ Make sure the battery is well connected.
- ⑥ Ensure that the external Off-grid contactor is well connected. (If applicable)
- ⑦ Turn on the Load switch and Off-grid switch.
- ⑧ Turn on the battery switch.

Long press the "Enter" key for 5 seconds to exit the Off mode.  
(The mode is factory defaulted as Off Mode)



## 5.9 Inverter Operation

### ➤ Before operation, check the inverter according to the following steps

- a) Check that the inverter is well fixed on the wall.
- b) Ensure that all ground wires are well tightened.
- c) Ensure that all DC and AC circuit breakers are disconnected.
- d) Ensure that all ground wires are well tightened.
- e) The AC output terminal is correctly connected to the mains.
- f) Ensure that all photovoltaic panels and inverters are properly connected. Unused DC connectors should be blocked with caps.

### ➤ Start the inverter

- When the photovoltaic panel generates enough power, the inverter will start automatically.
- Check the status of the LED and LCD screen, the LED is green, and the LCD screen displays the main interface.
- If the LED is not green, please check the following:
  - All connections are correct.
  - All external disconnect switches are closed.
  - The DC switch of the inverter is set to the "ON" position.

The following are 3 different states of inverter operation, which means that the inverter starts successfully.

**Waiting:** When the DC output voltage of the photovoltaic panel is higher than 100V (lowest starting voltage) and lower than 150V (lowest working voltage), the inverter waits for checking.

**Checking:** The inverter will automatically detect the DC input. When the DC input voltage of the photovoltaic panel is higher than 150V and the photovoltaic panel has enough energy to start the inverter, the inverter will enter the checking state.

**Normal:** When the inverter is working normally, the green light is always on. At the same time, the power is fed back to the grid, and the LCD displays the output power.

If it is the first time to boot, please follow the prompts to enter the setting interface.

#### Warning!

The input terminal of the inverter can be opened only when all the installation work of the inverter has been completed. All electrical connections must be performed by professionals in accordance with local regulations.



#### Note!

If it is the first time to operate the inverter, the system will automatically display setup guide. Please follow the setup guide to complete the basic inverter settings.

## 6 Firmware Upgrading

### ➤ Upgrade notes

Please read the following precautions before upgrading.

#### Warning!

- In order to upgrade the firmware smoothly, if the DSP and ARM firmware need to be upgraded, please note that ARM firmware must be upgraded first, then DSP firmware!
- Please make sure that the category format is correct, do not modify the firmware file name, otherwise, the inverter may not work!

#### Warning!

- For X1-Hybrid G4, ensure that the PV input voltage is greater than 100V (upgrade on sunny days). Please ensure that the battery SOC is greater than 20% or the battery input voltage is greater than 90V. Otherwise, it may cause serious failure during the upgrade process!

#### Caution!


- If the ARM firmware upgrade fails or stops, please do not unplug the U disk power off the inverter and restart it. Then repeat the upgrade steps.

#### Caution!

- If the DSP firmware upgrade fails or stops, please check whether the power is off. If it is normal, plug in the U disk again and repeat the upgrade.

### ➤ Upgrade preparation

- 1) Please check the inverter version and prepare a U disk (USB 2.0) and personal computer before upgrading.



#### Caution!

- Please make sure that the size of the U disk is smaller than 32G, and the format is fat16 or fat 32.

2) Please contact our service support through service@solaxpower.com to obtain the firmware, and store the firmware in the U disk according to the following path.

*Update:*



For ARM file: "update\ARM\618.00361.00\_Hybrid\_X1G4\_ARM\_V1.01.0710.usb";  
For DSP file: "update\DSP\618.00360.00\_Hybrid\_X1G4\_DSP\_V1.01.0710.hex";

➤ Upgrade steps


Step 1. Please save the "Upgrade" firmware in your U disk first, and press the "Enter" button on the inverter screen for 5 seconds to enter the OFF mode.



Step 2. Find the "update" port of the inverter, use a flat-blade screwdriver or coin with the same width to remove the waterproof cover, and insert the U disk.




Step 3. LCD operation, enter the upgrade interface "update", as shown below(a): Please press the up and down keys to select ARM, then press down to set "OK", press the enter key to enter the software version interface ;




Step 4. Please confirm the new firmware version again and select the firmware to upgrade. The upgrade takes about 20 seconds.


(d) When it is completed, the LCD screen returns to the "Update" page.



Step 5. For DSP: Please wait for 10 seconds. When "Update" page shown as below, press down to select "DSP" and then press Enter. Please confirm the firmware version again and press Enter to upgrade. The upgrade takes about 2 minutes.



(f)



(g)



(h)




(i)




(j)

Step 6. After the upgrade is completed, the LCD screen displays "Upgrade Successful".



(k)


Step 7. Pull off the U disk, press "Esc" to return to the main interface, and long press the enter key to exit the mode.



Tip: If the display screen is stuck on "X1-Hybrid G4" after the upgrade, please turn off the photovoltaic power supply and restart, and the inverter will restart and return to normal. If not, please contact our service @solaxpower.com for help.


## 7 Setting

### 7.1 Control Panel



Object	Name	Description
<b>A</b>	LCD Screen	Display inverter information on the LCD display.
<b>B</b>	LED Indicator light	Blue light: The inverter is in normal state or Off-grid mode. Blue flashing: The inverter is in waiting or checking status. Off: The inverter is in a fault state.
<b>C</b>	LED Indicator light	Green: The battery communication is normal and working normally. Green flashing: The battery communication is normal and in an idle state. Off: The battery does not communicate with the inverter.
<b>D</b>		Red light on: The inverter is in a fault state. Off: The inverter has no error.
<b>E</b>	Key Function	ESC button: Return from the current interface or function.
<b>F</b>	Key Function	Up button: Move the cursor to the upper part or increase the value.
<b>G</b>	Key Function	Down button: Move the cursor down or decrease the value.
<b>H</b>	Key Function	Enter button: Confirm selection.

## 7.2 Menu Structure



## 7.3 LCD Operation

The main interface is the default interface, the inverter will automatically return to this interface when the system started up successfully or not operated for a period of time.

The information of the interface is as below. "Power" means the instant output power; "Today" means the power generated within the day. "Battery" means the left capacity of battery energy.

Power	0W
Today	0.0KWh
Battery	80%
Normal	


### ➤ Menu interface

The menu interface is another interface for users to change settings or obtain information.

-When the LCD displays the main interface, click "OK" to enter this interface.

-The user can select up and down the menu, and press the "OK" key to confirm.


Menu
>System ON/OFF
Work Mode
System Status




#### ➤ System ON/OFF

"ON" indicates that the inverter is in working state, which is generally the default state.

"OFF" means that the inverter stops running and only the LCD screen is turned on.



#### ➤ Mode Selection



Mode selection, there are 4 working modes to choose from.

Name	Description
Self Use	<p>The self-use mode is suitable for areas with low feed-in subsidies and high electricity prices.</p> <p>① When the power of PV is sufficient Active Charging or Discharge time period: PV will power the loads firstly, and surplus power will charge to the battery. If the battery is fully charged, then sell the surplus power to the grid; (The inverter will limit the output if Feed-in limit or zero feed-in is needed ) (PV &gt; Load ,PV → Load→Battery → Grid)</p> <p>② When the power of PV is insufficient Active Charging time period: PV will power the loads firstly, the remaining power will be taken from the grid, the battery will not discharge at this time. (PV &lt; Load ,PV + Grid → Load)</p> <p>Active Discharge time period: PV+BAT will power the loads together. If the power is still not enough, the remaining power will be taken from the grid. (PV &lt; Load ,PV + Battery + Grid → Load)</p> <p>③ Without PV power Active Charging time period: The grid supplies the loads and also can charge the battery; (PV=0 , Grid → Load + Battery)</p> <p>Active Discharge time period: The battery will power the home loads firstly. If the battery power is not enough, the remaining power will be taken from the grid. The inverter will enter into the stand-by state. (PV=0 , Battery + Grid → Load )</p> <p>Battery min SOC can be set: 10%-100%</p>
Feed-in priority	<p>The Feed-in priority mode is suitable for areas with high feed-in subsidies, but has feed-in power limitation.</p> <p>① When the power of PV is sufficient Active Charging time period: PV will power the loads firstly, and surplus power will feed-in to the grid. If the feed-in power has been limited, the surplus power can charge the battery. (PV&gt;Load ,PV → Load → Grid → Battery)</p> <p>Active Discharge time period: PV will power the loads firstly, and surplus power will feed-in to the grid. (PV&lt;Load ,PV → Load → Grid )</p>

Feed-in priority	<p>② When the power of PV is insufficient Active Charging time period :PV will power the loads firstly, the remaining power will be taken from the grid. The battery will not discharge. (PV&lt;Load ,PV+ Grid → Load) Discharge time period: PV+BAT will power the loads together. If the power is still not enough, the remaining power will be taken from the grid. (PV&lt;Load ,PV + Battery + Grid → Load)</p> <p>③ Without PV power Active Charging time period :The grid will power the home loads and also charge the battery; (PV=0 ,Grid → Load +Battery) Active Discharge time period :The battery will power the home loads firstly .If the battery power is not enough, the remaining power will be taken from the grid. The inverter will enter into the standby state. (PV=0 ,Battery+Grid → Load) Battery min SOC can be set:10%-100%.</p>
Backup mode	<p>The back-up mode is suitable for areas with frequent power outages. Same working logic with "Self-use" mode. This mode will maintain the battery capacity at a relatively high level.(Users' setting) to ensure that the emergency loads can be used when the grid is off. Customers no need to worry about the battery capacity. Battery min SOC can be set:30%-100%.</p> <p>Backup mode SOC adjustment range :30%-100%;In Backup mode, SOC-min under off-grid condition is 10%, which cannot be modified.</p>
Off-grid	<p>The off-grid mode is used when the power grid is off .System will provides emergency power through PV and batteries to supply power to the household loads. (Battery is necessary)</p> <p>① When the power of PV is sufficient PV will power the loads firstly, and surplus power will charge to the battery.(PV&gt;Load,PV → Load → Battery)</p> <p>② When the power of PV is insufficient The remaining power will be taken from the battery. (PV&lt;Load ,PV+Battery → Load)</p> <p>③ Without PV power The battery will power the emergency loads until the battery reached the min SOC,then the inverter will enter into the idle mode. (PV=0 ,Battery → Load)</p>

Note: in the case of grid connection, all working modes work normally when the battery SOC >5%.When the battery charge rate is below 5%, the PV or Grid will first charge the battery SOC 11%, and then return to the working mode selected by the user.


- Manual mode (manual mode), there are three options to choose from: forced charging, forced discharge, stop charging and discharging (grid-connected 0 power).

Work Select  
>Manual  
Forced Charge

Work Select  
>Manual  
Forced Discharge

Work Select  
>Manual  
Stop Cha&Discha

### ➤ System Status



System status contains six content:PV1/PV2/Battery/On-grid (energy feed into or buy from the grid)and Off-grid and so on. Press up and down to select, press "Enter" to confirm the selection, and press "ESC" to return to the menu.

a/b) PV1, PV2

Here you can see the voltage, current and power of the pv1 and PV2.photovoltaic panels respectively;

**PV1**

>U	0.0V
I	0.0A

**PV2**

>U	0.0V
I	0.0A

c) Battery

This status shows the battery condition of the system. Including battery voltage and battery current, Battery power, battery capacity, battery temperature, BMS connection status. The meaning of the sign of battery current and power: "+" means charging; "-" means discharging.

**Battery**

U	400.0V
I	-1.0A
P	-400W

## d)On-grid

Here you can see the voltage, current, frequency, and power of the grid.

On-grid	
U	0.0V
I	0.0A
P	0.0W

## e) Off-grid

Here you can see the voltage, current, frequency and power of the inverter when it is disconnected from the grid.

Off-grid	
U	0.0V
I	0.0A
P	0.0W

## f)Meter/CT


Here you can see the data showing the meter or the CT.

Meter/CT	
>Meter/CT-1	
Meter/CT-2	

Meter/CT	
>Meter/CT-1	
4000W	

Meter/CT	
>Meter/CT-2	
4000W	

## &gt; History Yield



The history data contains five pieces of information: on-grid power of the inverter, off-grid power generation, power of the meter/CT and error logs.

Press up and down to select, press Enter to confirm selection, and press ESC to return to the menu.

## a)On-grid

Here is a record of the power capacity of the inverter connected to the grid today, yesterday, this month, last month and the total.

On-grid	
Output Today	
Output Total	
Input Today	


## b)Off-grid

Here you can see the off-grid output of the inverter today, yesterday, this month, last month and the total output.

Off-grid	
Today	
Total	00.0KWh


## c) Meter / CT-1

Here you can see the inverter's electricity sold, total electricity sold, electricity bought from the grid and total electricity bought on that day.




## d) Meter / CT-2

Here you can see the total power output of the inverter for the day.




## e) Error Logs


Here you can see the most recent six error messages.



## ➤ Settings



Here you can set the inverter time, language, working mode, charging and discharging time period and user password.




## a) Date time

This interface is for users to set the system date and time.




## b) Language

This inverter provides multiple languages for customers to choose.




## c) Off-grid Mute

Here you can choose whether the buzzer is turned on when the inverter is running in off-grid mode. Select Yes, the buzzer mutes, select NO, off-grid mode, the buzzer will sound once every 4s when the battery is fully charged, the closer the battery is to the empty state, the higher the buzzer will sound, to remind users to avoid battery loss .




## e) Self-use mode

In this mode, you can set the minimum reserved battery power percentage and set the battery upper limit power.




## d) Feed-in Priority mode

In this mode, you can set the minimum battery reserve power.



## f) Backup mode


In this mode, you can set the minimum battery reserve power.



## g) Charge and discharge time


Here you can set the charge and discharge time period.

If two charging and discharging periods are needed, turn on the charging and discharging period 2 and set the period.



## h) User Password

The default password for the end user is "0000", where you can reset the new password and press the up/down key to increase or decrease the value. Press "Enter" to confirm the value and jump to the next digit. When all passwords have been entered and confirmed, press "OK" to set the password successfully.



## ➤ Advance settings

- Safety Code** a)
- Grid Parameters** b)
- Export Control** c)
- Meter/CT Settings** d)
- SelfTest** e)
- Shadow Fix** f)
- Modbus** g)
- X1-Matebox Setting** h)
- Power Factor** i)
- Pu Function** j)
- VRT Function** k)
- Power limit** l)
- DRM Function** m)
- Main Breaker Limit** n)
- Reset** o)
- Advance Password** p)

All advanced settings can be set here, such as battery, grid, off-grid, etc. "Advanced" setting is generally customization and resetting for battery and grid. Each part has lower level parts. Please contact your installer or factory and enter the installer password.



\* Please note that when the inverter DSP communication fails, all advanced settings will be hidden.



## a) Safety Code

User can set safety standard according to different countries and grid tied. There are now 1 standards to choose from. (The here may be changes in the future, please refer to the screen display)







Item	Standard	Country
1	ARN 4105	German

- OverVoltage\_L1**
- UnderVoltage\_L1**
- OverFreq\_L1**
- UnderFreq\_L1**
- Vac 10min Avg**
- OverVoltage\_L2**
- UnderVoltage\_L2**
- OverFreq\_L2**
- UnderFreq\_L2**
- OverFreq\_L2**
- UnderFreq\_L2**
- Tovp\_L1**
- Tuvp\_L1**
- Tofp\_L1**
- Tovp\_L2**
- Tuvp\_L2**
- Tofp\_L2**
- Tufp\_Fast**
- Reconnection Time**
- Checking Time**
- W(Gra)**
- OFPL\_StartPoint**
- OFPL\_SetRate**
- OFPL\_DelayTime**
- UFPL\_StartPoint**
- UFPL\_SetRate**
- UFPL\_DelayTime**

## b) Grid Parameters

Here you can set the protection value of grid voltage and frequency. The default value is the specified value under the current safety regulations, and the user cannot change it.

The display content will be displayed according to the requirements of local laws and regulations, which are constantly increasing. Please refer to the contents displayed on the inverter screen.



## c) Export Control



This feature allows the inverter to control the amount of electricity output to the grid.

The factory value is the default and can be changed by the user. The user value set by setup must be less than the maximum. If the user does not want to supply power to the grid, set it to 0.



## d) Meter/CT Settings

The user needs to select the CT or electricity meter to connect the inverter here. Select the address of the meter. CT does not need to select the address.



## e) Self Test (only for CEI 0-21)

The self test function allows users to test the following items. "Full test", "Ovp(59.S2) test", "Uvp (s1) test", "Uvp (27. S2) test", "Ofp (81> S1) test", "Ufp (81 <S1) test", "Ufp (81> S2) test", "Ufp (81 <S2) test", "Ovp10 (59. s1) test".








In the self-test interface, the user can select "all tests" or a single test item for testing.

Before testing, make sure that the inverter is connected to the grid.

All tests take about 6 minutes. And it will display "Success" and then "Delivery".


For a single test item, it takes about a few seconds or minutes.

Click "Test Report" to view the test results of all items.



## f) Shadow Fix

Here, you can set the shadow tracking with four options, which are off, low, medium, and high.




## g) Modbus

Here you select the baud rate of the external communication protocol, the default location of 19200 and 485 addresses.



## h) X1-Matebox Setting






If you want X1-Matebox installed, you need to turn this feature on here.



## i) Power Factor (applicable to specific countries, please refer to local grid requirements.)

There are 5 modes for selecting: Off, Under-Excited, Over-Excited, Curve, Q( u). (May be changed or added without notice)

User press up and down key to select, press enter key to confirm.




Mode	Comment
Off	-
Over-Excited	PF value
Under-Excited	PF value
Curve	Upper limit
	Lower limit
	Power Upper
	Power Lower
	PFlockInPoint ( CEI 0-21 only)
	PFlockOutPoint ( CEI 0-21 only)
	3Tau
Q(u)	VolTRATIO 1 ( AS4777.2 only)
	VolTRATIO 4 ( AS4777.2 only)
	QURESPONSEV2 ( AS4777.2 only)
	QURESPONSEV3 ( AS4777.2 only)
	QURESPONSEV4 ( AS4777.2 only)
	K Value (CEI 0-21 only)
Fixed Q Power	Q Power


- Reactive power control, reactive power standard curve  $\cos \phi = f(P)$

For VDE ARN 4105, the curve  $\cos \phi = f(P)$  should refer to curve B. The set default value is shown in curve B.


For e8001, the curve  $\cos \phi = f(P)$  should be curve A. The set default value is shown in curve A.

For CEI 0-21, the default value of PFlockInPoint is 1.05. When  $V_{ac} > 1.05V_n$ ,  $P_{ac} > 0.2 P_n$ , curve  $\cos \phi = f(P)$  corresponds to curve B.





- Reactive power control, reactive power standard curve  $Q = f(V)$



- PU Function (applicable to specific countries, please refer to local grid requirements)

The PU function is a volt-watt response mode required by certain national standards such as AS4777.2. This function can control the active power of the inverter according to the grid voltage.

Selecting "Enable" means that this function is turned on and is the default value.

Select "Disable" to deactivate the function.

<b>PU Function</b>
>PuFunction
Enable

<b>PU Function</b>
Response V2
220.0V

<b>PU Function</b>
Response V3
250.0V

<b>PU Function</b>
Response V4
265.0V

- LVRT Function (apply to 50549)  
Here you can set the high and low enable or disable.

<b>LVRT Function</b>	
Function Control	
Disable	Enable

- Power limit  
Power limit function, the maximum power of the AC port can be set by percentage.

<b>Power Limit</b>	
>Proportion	
1.00	

- DRM function (applied to NZS4777.2)  
The DRM function is a demand response method required by the NZS4777.2 standard and is only applicable to NZS4777.2.  
The default value is "enable". Select "Disable" to disable this function.


<b>DRM Function</b>	
>Function Control	
Enable	

- Main Breaker Limit  
Here you can set an open minimum current here.

<b>Main Breaker Limit</b>	
>Current	
40A	


## o) Reset

Users can reset the reset error log, meter power, inverter power, and restore factory settings here.




## p) Advance Password

Here you can reset the advanced password. "Set OK!" is displayed on success, and "Setup Failed!" will also be displayed on failure.




## ➤ Manufactory Setting



## a) DIO Function

The reserved functions will be displayed after being added later.



## b) Safety Mode

Safety scale, choose whether to be Italian safety.




## c) COM Port Select

Here external communication protocol or external indoor screen of the inverter can be set. When it is used for external communication protocol, it can choose RS485 or MOBUS. When it is used for external indoor screen, it can choose YES or NO.



## &gt; About




\* Register1 SN: Represents the serial number of external monitoring equipment, such as Pocket WiFi, Pocket LAN and Pocket GPRS.

## a) About

Here you can see some basic information of the inverter and battery, such as the inverter and battery model, SN number, software version number, and system run time.



## Inverter



## Battery

Battery >BatBrand.BAK	Battery >Bat-M SN 6S012345012345
Battery >Bat-PS1 SN 6S012345012345	Battery >Bat-PS2 SN 6S012345012345
Battery >Bat-PS3 SN 6S012345012345	Battery >Bat-PS4 SN 6S012345012345
Battery >BatteryMVersion 2.01	Battery >BatteryMVersion 2.01

## Internal Code

Internal Code >Inverter code 01 00 01 xx	Internal Code >BMS code
Internal Code >BAT-M 2.01	Internal Code >BAT-S1 1.01 50
Internal Code >BAT-S2 1.01 50	Internal Code >BAT-S8 1.01 50

## 8 Troubleshooting

## 8.1 Troubleshooting

This section contains information and procedures for resolving possible problems with X1-Hybrid G4, and provides you with troubleshooting tips to identify and solve most problems that may occur in X1-Hybrid G4. This section will help you narrow down the source of any problems you may encounter. Please read the troubleshooting steps below.

Check the warning or fault information on the system control panel or the fault code on the inverter information panel. If a message is displayed, log it before doing anything further.

Try the solutions indicated in the table below.

Number	Faults	Diagnosis and solution
IE 001	TZ Protect Fault	<p>Overcurrent fault.</p> <ul style="list-style-type: none"> <li>Wait for a while to check if you're back to normal.</li> <li>Disconnect PV+ PV- and batteries, reconnect.</li> <li>Or ask for help from the installer if it can not return to normal.</li> </ul>
IE 002	Grid Lost Fault	<ul style="list-style-type: none"> <li><b>Check battery input voltage if it's within normal range</b></li> <li><b>Or ask the Installer for help.</b></li> </ul>
IE 003	Grid Volt Fault	<p>Power grid voltage overrun</p> <ul style="list-style-type: none"> <li>Wait a moment, if the utility returns to normal, the system will reconnect.</li> <li>Please check if the grid voltage is within normal range.</li> <li>Or ask the installer for help.</li> </ul>
IE 004	Grid Freq Fault	<p>Electricity frequency beyond range</p> <ul style="list-style-type: none"> <li>If the utility returns to normal, the system reconnects.</li> <li>Or ask the installer for help.</li> </ul>
IE 005	PV Volt Fault	<p><b>PV voltage out of range</b></p> <ul style="list-style-type: none"> <li><b>Check the output voltage of the PV panel</b></li> <li><b>Or ask the Installer for help.</b></li> </ul>
IE 006	Bus Volt Fault	<ul style="list-style-type: none"> <li>press the 'ESC' key to restart the inverter.</li> <li>Check that the PV input open circuit voltage is in the normal range.</li> <li>Or ask the installer for help.</li> </ul>
IE 007	Bat Volt Fault	<p><b>Battery voltage fault</b></p> <ul style="list-style-type: none"> <li><b>Check battery input voltage if it's within normal range</b></li> <li><b>Or ask the Installer for help.</b></li> </ul>
IE 008	AC10M Volt Fault	<ul style="list-style-type: none"> <li>The grid voltage was out of range in the last 10 minutes.</li> <li>The system will return to normal if the grid returns to normal.</li> <li>Or ask the installer for help.</li> </ul>

Number	Faults	Diagnosis and solution
IE 009	DCI OCP Fault	DCI overcurrent protection fault. • Wait for a while to check if it's back to normal. • Or ask the installer for help.
IE 010	DCV OVP Fault	DCV Off-grid overvoltage protection failure. • Wait for a while to check if it's back to normal. • Or ask the installer for help.
IE 011	SW OCP Fault	<b>Software Detection of Overcurrent Fault</b> • Wait for a while to check if it's back to normal. • Shut down photovoltaic, battery and grid connections. • Or ask the installer for help.
IE 012	RC OCP Fault	Overcurrent protection fault. • Check the impedance of DC input and AC output. • Wait for a while to check if it's back to normal. • Or ask the installer for help.
IE 013	Isolation Fault	Insulation Fault • Please check the wire insulation for damage. • Wait for a while to check if it's back to normal. • Or ask the installer for help.
IE 014	Temp Over Fault	Temperature beyond limit • Check if ambient temperature exceeds the limit. • Or ask the installer for help.
IE 015	Bat Con Dir Fault	Off-grid mode current is too strong. • Ensure that the load power is within the Off-grid power range. • Check for any non-linear load connections on the Off-grid. • Move this load to check for recovery. • Or ask for help from the installer if it can not return to normal.
IE 016	Off-grid Overload Fault	Off-grid over load fault. • Shutdown the high-power device and press the 'ESC' key to restart the inverter. • Or ask for help from the installer if it can not return to normal.
IE 017	OverLoad Fault	On-grid mode over load • Shutdown the high-power device and press the 'ESC' key to restart the inverter. • Or ask for help from the installer if it can not return to normal.
IE 018	BatPowerLow	• Close the high-power device and press the "ESC" key to restart the inverter. • Please charge the battery to a level higher than the protection capacity or protection voltage.
IE 019	BMS Lost	Battery communication loss • Check that the communication lines between the battery and the inverter are properly connected. • Or ask for help from the installer if it can not return to normal.
IE 020	Fan Fault	Fan Fault • Check for any foreign matter that may have caused the fan not to function properly. • Or ask for help from the installer if it can not return to normal.
IE 021	Low Temp	Low temperature fault. • Check if the ambient temperature is too low. • Or ask for help from the installer if it can not return to normal.

Number	Faults	Diagnosis and solution
IE 022	ARM Unmatched	ARM software version mismatch Fault • update the software and press the ESC* key to restart the inverter. • Or ask for help from the installer if it can not return to normal.
IE 023	Other Device Fault	Other device Fault • update the software and press the ESC* key to restart the inverter. • Or ask for help from the installer if it can not return to normal.
IE 025	InterComms Error	Mgr InterCom Fault • Shut down photovoltaic, battery and grid, reconnect. • Or ask for help from the installer if it can not return to normal.
IE 025	InterComms Error	• Internal communication errors • Shut down photovoltaic, battery and grid connections. • Or ask for help from the installer if it can not return to normal.
IE 026	Inv EEPROM Fault	<b>Inverter EEPROM Fault</b> • Shut down photovoltaic, battery and grid, reconnect. • Or ask for help from the installer if it can not return to normal.
IE 027	RCD Fault	Fault of Residual Current Device • Check the impedance of DC input and AC output. • Disconnect PV+ PV- and batteries, reconnect. • Or ask for help from the installer if it can not return to normal.
IE 028	Grid Relay Fault	Electrical relay failure • Disconnect PV+ PV- grid and batteries and reconnect. • Or ask for help from the installer if it can not return to normal.
IE 029	Off-grid Relay Fault	Off-grid relay failure • Disconnect PV+ PV- grid and batteries and reconnect. • Or ask for help from the installer if it can not return to normal.
IE 030	PV ConnDirFault	PV direction fault • Check if the PV input lines are connected in the opposite direction. • Or ask for help from the installer if it can not return to normal.
IE 031	ChargerRelayFault	Charge relay fault • Press the ESC* key to restart the inverter. • Or ask for help from the installer if it can not return to normal.
IE 032	EarthRaleyFault	Off-grid earth relay fault • Press the ESC* key to restart the inverter. • Or ask for help from the installer if it can not return to normal.
IE 101	PowerTypeFault	Power type fault • Upgrade the software and press the ESC* key to restart the inverter. • Or ask for help from the installer if it can not return to normal.
IE 102	Port OC Warning	Off-grid port over current fault • Check that the off-grid load does not exceed the system requirements, and press the ESC* key to restart the inverter. • Or ask for help from the installer if it can not return to normal.

Number	Faults	Diagnosis and solution
IE 103	Mgr EEPROM Fault	<p>Manager EEPROM Fault.</p> <ul style="list-style-type: none"> <li>• Shut down photovoltaic, battery and grid, reconnect.</li> <li>• Or seek help from the installer if it can not return to normal.</li> </ul>
IE 104	DSPunmatched	<p><b>DSP version error</b></p> <ul style="list-style-type: none"> <li>• Check that the DSP1 version matches.</li> <li>• Or seek help from the installer if it can not return to normal.</li> </ul>
IE 105	NTC Sample Invalid	<p>NTC invalid</p> <ul style="list-style-type: none"> <li>• Make sure the NTC is properly connected and the NTC is in good condition.</li> <li>• Please confirm that the installation environment is normal</li> <li>• Or ask for help from the installer, if it can not return to normal.</li> </ul>
IE 106	Bat Temp Low	<p>Battery temp low</p> <ul style="list-style-type: none"> <li>• Check the battery installation environment to ensure good heat dissipation.</li> <li>• Or ask for help from the installer, if it can not return to normal.</li> </ul>
IE 107	Bat Temp High	<p>Battery temp high</p> <ul style="list-style-type: none"> <li>• Check the battery installation environment to ensure good heat dissipation.</li> <li>• Or ask for help from the installer, if it can not return to normal.</li> </ul>
IE 109	Meter Fault	<p>Meter error</p> <ul style="list-style-type: none"> <li>• Please check that the instrument is working properly</li> <li>• Or seek help from the installer if it can not return to normal.</li> </ul>
IE 110	BypassRaleyFault	<p>Bypass relay fault</p> <ul style="list-style-type: none"> <li>• Press the ESC* key to restart the inverter. .</li> <li>• Or ask for help from the installer if it can not return to normal.</li> </ul>
BE 001	BMS_External_Err	<p>Battery Error - External Communication Fault</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 002	BMS_Internal_Err	<p>Battery Error - Internal Communication Fault</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 003	BMS_OverVoltage	<p>Over voltage in battery system</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 004	BMS_LowerVoltage	<p>Low voltage in battery system</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 005	BMS_ChargeOCP	<p>Battery fault - over charge fault</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 006	BMS_DischargeOCP	<p>Battery fault-discharge over current fault</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 007	BMS_TemHigh	<p>Over temperature in battery system</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 008	BMS_TempSensor Fault	<p>Battery temperature sensor malfunction</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>

Number	Faults	Diagnosis and solution
BE 009	BMS_CellImbalance	<p>Battery Unbalanced failure</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 010	BMS_Hardware Protect	<p>Battery hardware protection failure</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 011	BMS_Circuit_Fault	<p>Battery circuit failure</p> <ul style="list-style-type: none"> <li>• Restart the battery .</li> <li>• Please contact the battery supplier.</li> </ul>
BE 012	BMS_ISO_Fault	<p>Battery insulation failure</p> <ul style="list-style-type: none"> <li>• Check that the battery is properly grounded and restart the battery.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 013	BMS_VolSen_Fault	<p>Battery voltage sensor fault</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 014	BMS_TemppSen_Fault	<p>Temperature sensor failure</p> <ul style="list-style-type: none"> <li>• Restart the battery .</li> <li>• Please contact the battery supplier.</li> </ul>
BE 015	BMS_CurSensor Fault	<p>Battery current sensor fault</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 016	BMS_Relay Fault	<p>Battery relay failure</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 017	BMS_Type_Unmatch	<p>Battery type failure</p> <ul style="list-style-type: none"> <li>• Upgrade the battery BMS software.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 018	BMS_Ver_Unmatch	<p>Battery version mismatch failure</p> <ul style="list-style-type: none"> <li>• Upgrade the battery BMS software.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 019	BMS_MFR_Unmatch	<p>Battery manufacturer did not match the fault</p> <ul style="list-style-type: none"> <li>• Upgrade the battery BMS software.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 020	BMS_SW_Unmatch	<p>Battery hardware and software mismatch failure</p> <ul style="list-style-type: none"> <li>• Upgrade the battery BMS software.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 021	BMS_M&S_Unmatch	<p>Battery master slave control mismatches</p> <ul style="list-style-type: none"> <li>• Upgrade the battery BMS software.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 022	BMS_CR_NORespond	<p>Battery charging request does not respond to a fault</p> <ul style="list-style-type: none"> <li>• Upgrade the battery BMS software.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 023	BMS_SW_Protect	<p>Battery slave software protection failure</p> <ul style="list-style-type: none"> <li>• Upgrade the battery BMS software.</li> <li>• Please contact the battery supplier.</li> </ul>
BE 024	BMS_536_Fault	<p>Battery fault-discharge over current fault</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>
BE 025	BMS_SelfcheckErr	<p>Over temperature in battery system</p> <ul style="list-style-type: none"> <li>• Please contact the battery supplier.</li> </ul>

Number	Faults	Diagnosis and solution
BE 026	BMS_TempdiffErr	Battery temperature sensor malfunction • Please contact the battery supplier.
BE 027	BMS_BreakFault	Battery Unbalanced Failure • Please contact the battery supplier.
BE 028	BMS_Flash_Fault	Battery hardware protection failure • Please contact the battery supplier.
BE 029	BMS_Prefcharge_Fault	Battery precharge failure • Please contact the battery supplier.
BE 030	BMS_AirSwitch_Fault	Battery air switch failure • Check that the battery breaker is off. • Please contact the battery supplier.

- If the information panel of your inverter does not show the fault light, check the following list to ensure the current installation status, correct operation.
  - Is the inverter located in a clean, dry and well-ventilated place?
  - Is the DC input circuit breaker open?
  - Is the specification and length of the cable adequate?
  - Are the input and output connections and wiring in good condition?
  - Is the configuration set correct for your particular installation?

please contact SolaX customer service for further assistance. Please be prepared to describe the details of your system installation and provide the inverter serial number.

## 8.2 Routine Maintenance

Inverter do not require any maintenance or correction in most cases, but if the inverter often loses power due to overheating, this can be attributed to the following reason:

- **heat sink behind the inverter is covered with dirt.**

If necessary, clean the cooling heat sink with a soft dry cloth or brush. Only trained and authorized professionals familiar with safety requirements can perform maintenance and maintenance work.

### ➤ Safety inspections

Safety checks should be conducted at least every 12 months, please contact the manufacturer to arrange for appropriate training, expertise, and practical experience in performing these tests. (Please note that this action is not covered by warranty). These data should be recorded in the device log. If the equipment is not running properly or any test fails, the equipment must be repaired for details of safety inspections, refer to section 2 of this manual for safety instructions and europe commission instructions.

### ➤ Regular maintenance

#### Only qualified people can do the following work

In the process of using frequency converter, the manager should check and maintain the machine regularly. The specific operation is as follows.

1. Check whether the heat sink is covered with dirt, clean the inverter and absorb dust if necessary. This work should be performed from time to time.
2. Check whether the frequency converter indicator is normal, check whether the frequency converter button is normal, check whether the frequency converter display is normal. This inspection should be conducted at least every 6 months.
3. Check the input and output lines for damage or aging. This inspection should be conducted at least every 6 months.
4. Cleaning and safety inspection of PV modules should be carried out at least once every 6 months.

## 9 Decommissioning

### 9.1 Disassemble of Inverter

- Remove DC input line and AC output line of inverter.
- Wait for at least 5 minutes to power off.
- Remove all cable connections from the inverter.
- Remove inverter from finger support the bracket.
- Remove the bracket if necessary.

### 9.2 Packing

Load the inverter into the original package if possible.

- If the original package can not be found, you can also use the following requirements of the carton packaging:

Bearing capacity of more than 30kg.

Easy to carry.

Can completely seal the cover.

### 9.3 Storage and Transportation

Store the inverter in a dry, temperature -40°C~70°C environment. Pay attention to less than four inverter on each stack board during storage and transportation.

### 9.4 Waste Disposal

If it is necessary to scrap the inverter or other related parts, be sure to send the waste inverter and packaging materials to the designated location for recycling by the relevant department.

## 10 Disclaimer

The XI-Hybrid G4 series hybrid inverters are transported, used and operated under limited condition, such as environmental, electrical etc. SolaX shall not be liable to provide the service, technical support or compensation under conditions listed below, including but not limited to :

- Inverter is damaged or broken by force majeure (such as earthquake, flooding, thunderstorm, lighting, fire hazard, volcanic eruption etc).
- Inverter's warranty is expired and doesn't buy extended warranty.
- Can't provide the inverter's SN, warranty card or invoice.
- Inverter is damaged by man-made cause.Inverter is used or operated against any items in local policy.
- Inverter's installation, configuration, commissioning doesn't follow the requirements mentioned in this manual.
- Inverter is installed, refitted or operated in improper ways mentioned in this manual without authority from SolaX.
- Inverter is installed, operated under improper environment or electrical condition mentioned in this manual without authority from SolaX.
- Inverter is changed, updated or disassembled on hardware or software without authority from SolaX.
- Obtain the communication protocol from other illegal channels.
- Build monitoring, control system without authority from SolaX.
- Connect to other brands batteries without authority from SolaX.

SolaX will keep right to explain all the contents in this user manual.